

Scan here for instructions



Important notes:

- 1) Do NOT use pipe tape or sealant on any "swivel" fitting (anything with a rubber cone seal or flat washer in it)
- 2) Do NOT over tighten any of the fittings with rubber seals. Snug plus a little more is all that's needed to seal. Over torquing fittings can damage the seals
- 3) Hoses are all labeled and match the labels next to hoses on the diagram

Testing

- 1) Turn the selector valve to "use tank"
- 2) Turn the water pump on.
- 3) Bleed air from each fixture by turning hot/cold on at sink, shower, rear shower, and flushing toilet until there's no air coming out
- 4) Leave pump on for 20 minutes and listen for the pump to cycle while visually checking for leaks. If the pump cycles, you may have a leak.

